



Trailer Fastening Systems

Aerosmith's PowerPin System is the fastest and easiest method available for trailer floors and sidewall installation.



Benefits of Pin Fastening

- ↓ Installs 7-10 Times Faster
- ↓ Less worker fatigue
- ↓ Easily drives into steel up to 5/16"
- ↓ Trailer floors and side walls
- ↓ Easy maintenance



aerosmith[®]

*Defining the Standard
For Steel & Concrete
Fastening*






Trailer Flooring Pins

Item	Length	Qty/Box	Knurl	Tool
3388HP	1-1/2" (38mm)	1.5 M	Double Knurl	HN120 with 10297LH nose
3488HP	1-7/8" (48mm)	1.5 M	Double Knurl	HN120 with HN10297LH nose
5573HPG	2-1/4" (57mm)	1 M	Smooth	HN120
5574HPG	2-1/4" (57mm)	1 M	Helical	HN120
5633HPG	2-1/2" (63mm)	1 M	Smooth	HN120

Side Walls

Item	Length	Qty/Box	Knurl	Tool
2227HPX	7/8" (22mm)	2 M	Helical	HN25C
2257HPX	1" (25mm)	2 M	Helical	HN25C
3258A	1" (25mm)	2 M	Double Knurl	ST4200BA

Removing Phillips Headed Pins

Items Needed	
	#1 Phillips Bit for 2257 (Sidewalls) #2 Phillips Bit for 3258 (Sidewalls) #2 Phillips Bit for 3388 (Floors)
	Corded or Cordless Impact Driver *do not use a standard "drywall type" screw gun*
	Pry-Bar

1. Use and impact driver, to twist and break head from the shank of the pin. Forced Entry Pins WILL NOT back out like a screw. The impact tool will break the head or cause the shank to spin loose.
2. After step 1 use a pry bar if necessary, however once you have broken the pins loose, the board will typically come up easily.

aerosmith®

Aerosmith™ Fastening Systems
5621 Dividend Road, Indianapolis, IN 46241
Ph: 800.528.8183 Fax: 317.390.6980
www.AerosmithFastening.com

