allure®

## Transitional Shades

Large Cassette

## Installation Instructions

Thank you for choosing your Allure Transitional Shade
With proper installation and care, your new shades will provide many years of beauty and performance.

Before Installing

Remove shade from the package. Keep all packaging until shade operates to your satisfaction. Contents of your hardware package may vary depending on options chosen.
Additional fasteners may be needed on your specific mounting surface (not included).

Tools Needed

Pencil	Screw Driver	Level	Measuring tape	Drill

Shade Width	Brackets Required	2-on-1 Headrail
15" - 48" 48 1/16" - 72" 72 1/16" - 90" 90 1/16" - 120" 120 1/16" - 156"	2 3 4 5 6	If installing a 2-on-1 headrail: one bracket is required to be located at the Center Gap

Step 1 — **Space Brackets in Window**

Measure 2" in from each end of the headrail and mark the bracket location on the mounting surface.

Space additional brackets evenly between the end brackets and mark the bracket location on the mounting surface

2" Max ⟶   ⟵ Space Evenly ⟶   ⟵ Space Evenly ⟶   ⟵ 2" Max

Note: install brackets into studs or headers when possible, and space evenly

If spacer blocks are being used, place in between mounting surface and bracket before attaching with screws

IMPORTANT: Brackets need to be Level and Aligned
Shimming Brackets may be required

Install the Brackets

Make sure the side marked Top is Up

INSIDE MOUNT   **OUTSIDE MOUNT**

IMPORTANT: Two screws are needed to attach each installation bracket

Use two screws to secure to the mounting surface

Step 3   **Install the Shade**

**Center Shade with Window Opening**

Tilt the front of the headrail Down

Rotate the front of the headrail from the front back into the bracket

Rotate the headrail until it snaps into place on the bracket

Rest the bottom back of the headrail on the bottom of the bracket

Step 4   **Operate the Shade**

Clutch

Pull gently on the back side of the chain to to lower it.

Pull gently on the front side of the chain to to raise it.

Accu-Rise

Find the Center of your Bottom Rail

Snap the Handle onto the rail in the center position

Pull Accu-Rise shade gently from the Handle to lower it.

Push up from center to raise it.

Troubleshooting:

If shade doesn't raise, the roller may be binding on the internal brackets.

Remove End Caps and gently pry the internal bracket away from the roller so that it moves freely

---

| Step 5	**Install Cord Tensioners**

Cord Tension Lock

Installers MUST INSTALL Cord Tension Lock Properly

Mark Mounting Position

Lower shade to make sure the Cord Tension Lock is not placed in the path of the bottom rail or fabric

Outside Mount

Inside Mount

Insert the nub of the Bracket into the Tensioner Center Hole

Pull the Chain taut with the Bracket on the mounting surface

Slide the Bracket and the Tensioner Center down to the Guide Lines on the Cord Tensioner

While holding the lock firmly in place, check that the loop can move freely through the Tensioner

The Center Hole of the Tensioner must be aligned with the guide lines

Mark the Bracket location on the Mounting Surface

If the Bracket is not Aligned properly:

If the Tensioner locks onto the loop, it is too loose and the bracket and lock should be **moved down**

If the loop does not run freely through the lock, it is too tight and the bracket and lock should be **moved up**

**Attach the Bracket to Mounting Surface**

Outside Mount   **Inside Mount**

Move Tensioner
out of the way and
attach to Mounting
Surface with the
Two Longer Screws
provided

Attach the Cord Tension Lock to Bracket

Outside Mount   **Inside Mount**

Pull the Tensioner's
spring loaded Slider
down to the bracket

a small tool may be
helpful in moving the
slider

Make sure the
Tensioner's Center
Hole is seated on the
nub of the bracket

Use the small screw
to attach Tensioner

Do not Overtighten

P-Clip Safety Tensioner

Position the Tensioner

Lower shade to make sure the P-Clip is not placed in the path of the bottom rail or fabric

Determine the
orientation of the P-Clip
Tensioner

With the shade securely installed, pull the chain taut then
relax the chain slightly then Mark the location of the P-Clip

Install the Tensioner

Make sure that the cord or chain is taut and moves freely through the Tensioner

Then secure to the mounting surface using the screw provided

IMPORTANT: the Tension Lock must be properly secured to the wall or window frame to reduce a child's access to the chain or cord loops.
Young children and pets can wrap chains around their necks and strangle themselves.

Determine the orientation of the
Hold Down Bracket

Remove Film from Magnet strips and attach to
Top and Bottom of the
Rail

Lower the shade to the closed
position and mark the Bracket
location where it attaches to the
TOP of the Rail

This allows the shade to be
opened while still attached to
the bracket

Secure HoldDown to the wall

| Step 6 | **Install Hold Down (optional)** |

**This Hold Down Option does not allow you to freely open and close the shade**

Lower the shade to the
closed position

line up the Hold Down bracket where the pin on the Rail
is at the bottom of the slot

This allows the shade to be
opened while still in the
bracket

Attach Bracket to
mounting Surface

Rotate the bottom rail to get the pins into
the brackets

Shade Removal

Using Direct Force
push the headrail
into the bracket

Apply force until the bracket is
pushed back far enough to clear
the tabs on top of the headrail

Rotate the Headrail
forward out of the
bracket to remove

18-8004-LGCASS   Mar. 2022

LAFAYETTE
interior fashions™